

Garmin Virb Elite Kneeboard Checklist

- › Press and hold the **MODE** button to turn on
- › Ensure the **RECORD** button is in the down position
- › Press **MODE** until **SETUP** appears then press **OK**
- › **WIFI** will appear, if **WiFi** is on, you may be all done. If you need more settings, keep reading.
- › Press **OK** and **WiFi** will turn off (that is **OK** for now).
- › Scroll up to **SETUP** and press **OK**
- › Now you will see other **SETUP** options.
- › Scroll to **SYSTEM** and press **OK**
- › (If you select the wrong option, press **Mode** to return to the higher-level menu)
- › Scroll down to **RESET SETTINGS**, press **OK**, select **YES** and press **OK**
- › Scroll to **CARD** and press **OK**
- › Scroll to **ERASE** and press **OK** to format the memory card
- › Press **OK** again to return to the **SETUP** options
- › Scroll to **PHOTOS** and press **OK**
- › Scroll to **SELF TIMER** and press **OK**
- › Select 5 seconds (or as requested) and press **OK**
- › Select **REPEAT ON** and press **OK** the press **MODE**
- › Scroll to **WIFI** and press **OK** (this will turn **WIFI** back on)
- › Verify **SSID** name (**VIRB-xxxx**) and password (**garminvirb**) and press **OK**
- › Press **MODE** button to return to regular operations
- › (Wait about 10 seconds for the camera display to turn back on)
- › Press and hold the **MODE** button to power off the Virb
- › Remove and recharge the battery when mission is complete



12 June 2022

Garmin Virb Elite Kneeboard Checklist

- Press and hold the **MODE** button to turn on
- Ensure the **RECORD** button is in the down position
- Press **MODE** until **SETUP** appears then press **OK**
- **WIFI** will appear, if **WiFi** is on, you may be all done. If you need more settings, keep reading.
- Press **OK** and **WiFi** will turn off (that is **OK** for now).
- Scroll up to **SETUP** and press **OK**
- Now you will see other **SETUP** options.
- Scroll to **SYSTEM** and press **OK**
- (If you select the wrong option, press **Mode** to return to the higher-level menu)
- Scroll down to **RESET SETTINGS**, press **OK**, select **YES** and press **OK**
- Scroll to **CARD** and press **OK**
- Scroll to **ERASE** and press **OK** to format the memory card
- Press **OK** again to return to the **SETUP** options
- Scroll to **PHOTOS** and press **OK**
- Scroll to **SELF TIMER** and press **OK**
- Select 5 seconds (or as requested) and press **OK**
- Select **REPEAT ON** and press **OK** the press **MODE**
- Scroll to **WIFI** and press **OK** (this will turn **WIFI** back on)
- Verify **SSID** name (**VIRB-xxxx**) and password (**garminvirb**) and press **OK**
- Press **MODE** button to return to regular operations
- (Wait about 10 seconds for the camera display to turn back on)
- Press and hold the **MODE** button to power off the Virb
- Remove and recharge the battery when mission is complete



22 June 2022