• GoPro Camera

- Looking at the front of camera, unlatch the left side panel from the side bottom, pull down, swing out.
- Insert/remove both battery and memory card.
- Push power button on right side.
- Open mount from bottom, attach a mounting extension.









 On rear LCD display, swipe down, then swipe left and tap on Preferences then Format SD Card.

• In iPad Quik app:

- Click on Preference icon, then bottom Time Lapse button, then TimeLapse pencil.
- Select: Lens=Linear, Interval=5s, Format=Time Lapse Photo, Output=Standard, Duration=No Limit, Timer=Off.
- Tap the red timer button to begin the GoPro recording.
 - Display will show # of photos taken.
- Start camera record when in target area (note time).
- Stop camera record when exiting target area (note time).